



Installation Tip / Troubleshooting

1

BEFORE ASSEMBLY




Remove the red pin before assembling the poles.



- ▶ Remove the red pin by pressing gently on the one-touch button and pulling the pin down.
- ▶ it is a tool necessary during the shipping process and can be thrown away.


Before assemble pole, Make sure to get rid of red pin from device.

In case, safety pin is broken.



- ▶ Push it in with another slim object, then it will fall and exit through the pole. Make sure to throw it away.

BEFORE DISASSEMBLY



- ▶ First, unscrew the safety bolt behind the one-touch button. Press the one-touch button to lower the upper pole. We strongly recommend that you hold onto the upper pole while lowering it by using one hand to hold the upper pole and the other to press the one-touch button.

2

Figure 1

Pull the upper pole slightly upward until the ceiling mount touches the ceiling. Mark it with a pencil as shown in Figure 1.





Figure 2

Push the upper pole to the ceiling as hard as you can. Make to have a gap about 15-25mm(0.6~1 inch) between marked line and the One-Touch device.



- If the marked line is too low or is not visible, pull the upper pole against the ceiling firmly to check if it is assembled properly.

▶ Installation Tip for PrinceHanger(Vertical Pole(s))


1. Pull the upper pole slightly upward until the ceiling mount touches the ceiling.
 2. Mark it with a pencil as shown in [Figure 1].
 3. Push the upper pole to the ceiling as hard as you can. Make sure to have a gap about 0.6~1 inch (15~25mm) between the markd line and the One-Touch Device. [Figure 2]
- ※ if the marked line is too low or is not visible, pull the upper pole against the ceiling firmly to check if it is assembled properly.

★ After installation of the vertical pole, please make sure to fasten the safety bolt .

→Video : <https://princehanger.com/troubleshooting/>

Installation Tip / Troubleshooting

3



- ※ if your item has adjustable Hanger Rod(s)
- ★ Hanger Rod (Horizontal bar) SHOULD NOT be extended to more than “66.5” inches for your safety

4

※ Limited Lifetime Warranty

◎ <https://princehanger.com/request-warranty/>

- ▷ Broken part that has been damaged under normal use will be covered by Princehanger.
- ▷ Lost part is not covered. / Lost part can be purchased from Princehanger.
- ▷ Damage due to improper installation, neglect, or misuse is not covered.
- ▷ The replacement part will be shipped at customer's expense.
- ▷ proof of purchase & The photo of the broken part will be required.
(Order Number or Product name & name of purchaser)
- ▷ The warranty is non-transferable.(Only the first buyer has the right to a warranty)



※ For Troubleshooting, please visit our website

● <https://princehanger.com/troubleshooting/>

※ Please contact us directly before you call the place of purchase (Amazon/Ebay/Walmart) for prompt customer support.

- ★ Email : princehanger@gmail.com / info@princehanger.com
- ★ Call : 847-769-6693