

IMPORTANT- PLEASE READ BEFORE ASSEMBLY

Safety Precautions



Please follow these safety precautions in order to ensure proper installation and to prevent any bodily injuries and structural failures.

*Please note that this unit includes poles and rods that are made out of steel, which can cause bodily injuries and/or damages to the floor if dropped or held in an improper manner during assembly.

1. This unit is designed for use by keeping the poles fixed to the floor and the ceiling. Therefore, it is not safe for children to climb or hang on the unit. Children should be under adult supervision at all times to prevent any injuries.

2. Overloading the unit might cause it to become unstable and either tip or collapse, which may cause serious bodily injury and/or damage to personal possessions.

3. In order to prevent any accidental collapses due to improper care, install the unit, so that it is slightly tilted towards the wall, not perpendicular to the floor.

4. We recommend that you frequently examine the unit for any loose bolts or wobbling.

BEFORE ASSEMBLY



Remove the red pin before assembling the poles.



Before assemble pole, Make sure to get rid of red pin from device.



- Remove the red pin by pressing gently on the one-touch button and pulling the pin down.
- It is a tool necessary during the shipping process and can be thrown away.

- Push it in with another slim object, then it will fall and exit through the pole. Make sure to throw it away.

BEFORE DISASSEMBLY



- First, unscrew the safety bolt behind the one-touch button. Press the one-touch button to lower the upper pole. We strongly recommend that you hold onto the upper pole while lowering it by using one hand to hold the upper pole and the other to press the one-touch button.


PRODUCT COMPONENTS

*Check your inventory before beginning installation.

1 Upper & Lower Pole (1 Set)



2 Upper Connecting Poles(1)



3 Safety Bolt (1)

[Used for the one-touch fastening device]

4 Ceiling Mount (1)



5 Floor Mount (1)



6 Hooks (6)




7 Rubber Rings (6)



PLEASE INSTALL ON A FLAT SURFACE.
Not doing so might cause it to become unstable and/or collapse.

Assembly Instructions


► Assemble the parts to the upper and lower poles in order as shown in the diagram.



1 Upper Connecting Pole

Connect the poles together by inserting the thinner end of the upper connecting pole to the upper pole.

Hook




The hooks adjust in height with the use of the rubber ring and rotate 360 degrees for use in any direction.

- The rubber ring helps keep the fixtures in place and should be inserted underneath each rod bracket. (The rubber rings inserted underneath the rod brackets are not visible after installation.)

The installation instructions are same for all products, regardless of the differences in color.

To Install the Poles,



Explanation:

- At the desired location, hold the lower pole with one hand and the upper pole with the other and push it up to the ceiling so that the pole is fixed upright to both the ceiling and the floor. (Make sure the pole is fixed securely on the ceiling by pushing the pole up as far as you can (which can extend up to 1 1/6 in. due to the spring mechanism in the ceiling mount))
- After installing the pole, tighten the safety bolt behind the one-touch fastening device by hand for safer use of the unit.

*Product Dimensions:

- Install Diameter : 17.8 in.
- Height: 67 in. ~ 117 in.

