



#### **SAFETY PRECAUTIONS**



Please note that this unit includes poles and rods that are made out of steel, which can cause bodily njuries and/or damages to the floor if dropped or held in an improper manner during assembly.

- 1. This unit is designed for use by keeping the poles fixed to the floor and the ceiling. Therefore, it is not safe for children to climb or hang on the unit. Children should be under adult supervision at all times to prevent any injuries.
- 2. Overloading the unit might cause it to become unstable and either tip or collapse, which may cause serious bodily injury and/or damage to personal possessions.
- 3. In order to prevent any accidental collapses due to improper care, install the unit, so that it is slightly tilted towards the wall, not perpendicular to the floor.
- 4. We recommend that you frequently examine the unit for any loose bolts or wobbling.






# **ASSEMBLY INSTRUCTIONS (POLE)** \*Assemble the parts to the upper and lower poles in order, as shown in the diagram. POLE 1 POLE 2 **6** Ceiling Mount **6** Ceiling Mount 4 Rod Bracket(1.26) 4 Rod Bracket(1.26) Rubber Ring Rubber Ring 2 Rod Bracket(1.26) 2 Rod Bracket(1.26) 1 Rubber Ring Rubber Ring **Rod Bracket** Used to support rods. Please assemble the U-shaped. Extend the upper pole about 20 in. before Extend the upper pole about 20 in. before assembling the parts assembling the parts in order, as shown in in order, as shown in the diagram. the diagram. One-Touch Fastening Device One-Touch Fastening Device

3



## To Install the Poles,




## **Explanation:**

- 12 At the desired location, hold the lower pole with one hand and the upper pole with the other and push it up to the ceiling so that the pole is fixed upright to both the ceiling and the floor. (Make sure the pole is fixed securely on the ceiling by pushing the pole up as far as you can (which can extend up to 1 1/6 in. due to the spring mechanism in the ceiling mount)
- 3. After installing the pole, tighten the safety bolt behind the one-touch fastening device by hand for safer use of the unit.


## **INSTALLATION TIP!!!**

## [Figure 1]

Pull the upper pole slightly upward until the ceiling mount touches the ceiling. Mark it with a pencil as shown in Figure 1.



[Figure 2] Push the upper pole to the ceiling as hard as you can. Make sure to have a gap about 15-25mm(0.6~1 inch)



•If the marked line is too low or is not visible, pull the upper pole against the ceiling firmly to check if it is assembled properly.

# INSTALLATION (POLE & OTHER FIXTURES)


(The rubber rings inserted underneath the rod brackets are not visible after installation.)

Floor Mount

To install poles and other fixtures,

The rubber ring helps keep the fixtures in place and should be inserted underneath each rod bracket.

**1** Floor Mount



- ①Set the poles upright and distance them apart to the desired width of the unit. ②After keeping the rod brackets level, fit the rods into the rod bracket as shown in the diagram.
- 3 Adjust the height of the rod brackets to the desired height using rubber rings and then gently tighten the safety bolt in the back by hand.

## ADES USA INC. (Princehanger)

Website: <a href="https://www.princehanger.com">https://www.princehanger.com</a> Email: <a href="mailto:Princehanger@gmail.com">Princehanger@gmail.com</a> / <a href="mailto:sales@princehanger.com">sales@princehanger.com</a>

Customer center: 847-769 6693 Hours: Monday ~ Friday / 8AM ~ 5PM (EST)