### INSTALLATION (POLE & OTHER FIXTURES)

rod bracket and then

keep it fixed.

**INSTALLATION (CURTAINS)** 

tighten the safety bolt to

### To install poles and other fixtures,

\*Refer to Page 4 for instructions on how to hang curtains. Hanger Rod Rod Rod Bracket Safety Bolt **Rod Brackets** Insert the hanger rod into One-Touch Fastening Device the rod bracket. Adjust the height of the

Pole 2

- (1) Set the poles upright and distance them apart to the desired width of the unit.
- (2) After keeping the rod brackets level, fit the rods into the rod bracket as shown in the diagram.
- 3 Adjust the height of the rod brackets to the desired height using rubber rings and then gently tighten the safety bolt in the back by hand.

#### \*Product Dimensions:

Width: 39.3~55.1in Height: 67~117 in. Depth: 13.8 in.

## To Hang Curtains

39.3~55.1in

Pole 1

## Installing Curtain Rod Brackets (1)



\*Tighten the tie bolt on the other side of the nut



Keeping the curtain rod brackets level, attach them to the upper poles. Tighten the tie bolt on the other side of the nut. (The nut is only on one side of the bracket.)

### Installing Curtain Rod Brackets (2)



### **Finished Product**



### SAFETY PRECAUTIONS

Please follow these safety precautions in order to ensure proper installation and to prevent any bodily injuries and structural failures.

Please note that this unit includes poles and rods that are made out of steel, which can cause bodily injuries and/or damages to the floor if dropped or held in an improper manner during assembly.

- 1. This unit is designed for use by keeping the poles fixed to the floor and the ceiling. Therefore, it is not safe for children to climb or hang on the unit. Children should be under adult supervision at all times to prevent any injuries.
- 2. Overloading the unit might cause it to become unstable and either tip or collapse, which may cause serious bodily injury and/or damage to personal possessions.
- 3. In order to prevent any accidental collapses due to improper care, install the unit, so that it is slightly tilted towards the wall, not perpendicular to the floor.
- 4. We recommend that you frequently examine the unit vvfor any loose bolts or wobbling.
- 5. The curtains should be hand washed. They are not machine-washable.

#### Please note

**Product Components** 

The unit may collapse if it is not securely fixed to the floor or if it is installed to a weak part of the ceiling.


One-Touch Fastening Device

Lower Pole (1.26 in.)

Floor Mounts (2)

Safety Bolts (2)

Curtain (1)





slim object, then it wil fall and exit through the pole. Make sure to


\*Check your inventory before beginning installation.

## COMPLETE PARTS LIST



[Used for the one-touch fastening device]







## **ASSEMBLY INSTRUCTIONS (POLE)**

Assemble the parts to the upper and lower poles in order, as shown in the diagram.

## Pole 1 Pole 2 **6** Ceiling Mount **6** Ceiling Mount Attach the curtain rod bracket Attach the curtain rod bracket after installing the pole. Refer after installing the pole. Refer to Page 6 for more information. to Page 6 for more information. A Rod Brackets A Rod Brackets 3 Rubber Ring 3 Rubber Ring Rod Bracket Used to support rods. Please assmble the bracket so theat it is U-shaped. 2 Rod Brackets 2 Rod Brackets 1 Rubber Ring Rubber Ring Upper Connecting Pole (Thinner Pole) Upper Connecting Pole (Thinner Pole Connect the poles Connect the poles together by inserting the together by inserting the thinner end of the upper thinner end of the upper connecting pole to the connecting pole to the upper pole. upper pole. Upper Pole Upper Pole One-Touch Fastening Device One-Touch Fastening Device Lower Pole Lower Pole (Thicker Pole) (Thicker Pole) Floor Mounts Floor Mounts

## **INSTALLATION (POLE)**

## To Install the Poles,



# **Explanation**

- 1 2 1,2 At the desired location, hold the lower pole with one hand and the upper pole with the other and push it up to the ceiling so that the pole is fixed upright to both the ceiling and the floor. (Make sure the pole is fixed securely on the ceiling by pushing the pole up as far as you can (which can extend up to 1 1/6 in. due to the spring mechanism in the ceiling mount)
  - After installing the pole, tighten the safety bolt behind the one-touch fastening device by hand for safer use of the unit.